The current value is not increasing

1. **Issue Description:**
   When the washer or dryer starts its cycle, the current value does not increase as expected. Consequently, the app display does not change from blue to green.











Possible Cause:

There may be an issue with the current sensor, communication between the device and the app, or a delay in data update during the start of the cycle.

Recommendation:

Check the wiring connection between the current sensor and the Alpha-1 device, ensure sensor clip tighten to device properly, and verify that the threshold at node cloud increasing during the machine running.

Clip the given split-core current transformer at the Live wire.









Revision #11
Created 2025-11-05 05:12:48 UTC by Sulaiza
Updated 2025-11-12 03:37:27 UTC by Sulaiza